

## Helpful Hints

### Profiler B-Series

- Use of a C-Shape handle is recommended for this application. Alpha® Profilers are WET USE ONLY for LOW-SPEED applications. Do not allow the nylon guide to free-spin during application as scratches on the surface of material may occur from slurry residue. The Alpha Professional Tools® logo on the nylon guide should be clearly displayed during profiling application when using the Alpha® Profiler correctly.
- Use plenty of water during application. Use of water will flush away excess slurry from surface.
- For proper use of the Alpha® Profilers, see attached "How To Use".